



## Specifications: ProClean No Odor Mastic Remover 5 gallon Pail and 55 Gallon Drum

Appearance:	Clear
Odor:	Extremely Low
Boiling Point:	>390 - 412 F
Freezing Point:	< -94 F
Vapor Density:	Heavier than Air
pH:	Neutral
Flash Point:	>145 F (TCC)
DOT Shipping Class:	70
Shipping Weight:	5 gal. pail 38 lbs. 55 gal. drum 422 lbs.
Specific Gravity:	0.800 - 0.820
Solubility in Water:	Nil
Coverage Rate:	100 - 125 sq. ft./gal
Reactivity:	Stable
HFIS Rating:	1-2-0
Shelf Life:	None
NMFC#:	48580

DOT Shipping Name: Not DOT Regulated  
On containers less than 120 gallons

**Twin-Chemicals**  
**Atlanta, Georgia**

**(800) 442-4958**

**www.twinchemicals.com**  
**sales@twinchemicals.com**



**ProClean No Odor Mastic Remover is designed to give you the maximum power while still being a no odor product. It quickly cuts through mastic to get the job done and has a superior surfactant system that allows for easy rinsing and final cleaning. This product will get the job done with fewer odor complaints while dissolving the mastic with the speed you desire.**

1. Read and understand the safety data sheet (SDS) when using this product.
2. Prepare a safe work area. Using plastic sheeting, cover walls, windows, air vents, drains, cracks, carpeting, woodwork and any other porous materials that may come in contact with the mastic remover. Set up decontamination chambers and a negative air system. Remove floor tile according to local and federal regulations.
3. Apply **ProClean™ No Odor Mastic Remover** to the defined areas, either manually or with a pump sprayer until areas are completely saturated. Do not let the mastic remover splash onto any porous areas (drywall, wood, etc.). Agitate the product with a stiff bristled broom or brush.
4. Allow the mastic remover to penetrate and soften the adhesive for at least 20-30 minutes. Some mastic may require a longer dwell time.
5. After the mastic has dissolved, use a squeegee to collect liquefied mastic into a pile and use **Mastasorb Absorbent** to soak up liquid. Dispose waste according to local and federal regulations.
6. Once the adhesives have been satisfactorily removed, use **Pronto Extra Wetter™**, to wet out any remaining particles to make certain they don't become airborne.
7. The final step is to use a heavy-duty degreaser, such as **DeSolv Degreaser™**, to remove residual mastic remover from the substrate and to speed up the time between mastic removal and resurfacing. The degreaser is applied straight and scrubbed into the surface as water is added, with agitation, to 'float' the solvent out of the substrate.
8. Allow the surface to dry a minimum of 72 hours before applying new mastic and/or new flooring. In most cases and under normal conditions of ventilation, temperature and intact substrate. Any variation from these conditions can prolong drying time. Lower odor and higher flash point products dry more slowly than higher odor and lower flash point products.
9. Finally, test the substrate by sprinkling a few drops of water onto the surface. If they spread out and soak in, the floor is ready. However, if the water beads up like water on a newly waxed car surface, you need to re-clean as above. This is recommended for all applications.

**WARRANTY NOTICE:** Seller makes no warranty, expressed or implied, nor accepts any responsibility for any direct or consequential damages beyond the purchase price, because seller cannot control users handling and use, or effect of use.