

Specifications: M3-205 No Odor Mastic Remover 5 gallon Pail and 55 Gallon Drum

Appearance: Clear

Odor: Odorless

Boiling Point: >400

Vapor Density: NA

pH: NP

Flash Point: > 228 F (TCC)

DOT Shipping Class: 70

Shipping Weight: 5 gal. pail 38 lbs.

55 gal. drum 423 lbs.

Specific Gravity: 0.810—0.830

Solubility in Water: Nil

Coverage Rate: 100 - 125 sq. ft. / gal

HFIS Rating: 1-2-0

Shelf Life: None

NMFC: 48580

DOT Shipping Name: Not DOT Regulated on containers less than 120 gallons

Twin-Chemicals Atlanta, Georgia

(800) 442-4958 (770) 924-6147 fax

www.twinchemicals.com



M3-205 is a CARB Compliant mastic remover with a flash point over 228 degrees F. The product has no odor and is easily rinsed with water. This is a great product for your "sensitive" jobs. Contractors love this product for jobs in hospitals, on airbases, or in schools. The very high flash point makes this one of the safest mastic removers in the marketplace.

Directions:

- 1. Read and understand the safety data sheet (SDS) when using this product.
- 2. Prepare a safe work area. Using plastic sheeting, cover walls, windows, air vents, drains, cracks, carpeting, woodwork and any other porous materials that may come in contact with the mastic remover. Set up decontamination chambers and a negative air system.
- 3. Remove floor tile according to local and federal regulations.
- 4. Apply **M3-205** with a pump sprayer until areas are completely saturated. Do not let the mastic remover splash onto any porous areas (drywall, wood, etc). Agitate the product with a stiff bristled broom or brush.
- 5. Allow the mastic remover to penetrate and soften the adhesive for at least 20-30 minutes. Some mastic may require a longer dwell time.
- 6. After the mastic has dissolved, use a squeegee to collect liquefied mastic into a pile and use **Mastasorb Absorbent** bales to soak up liquid. Dispose waste according to local and federal regulations.
- 7. Once the adhesives have been satisfactorily removed, use a wetting agent, **Pronto Extra Wetter**, to wet out any remaining particles to make certain they don't become airborne.
- 8. The final step is to use a heavy-duty degreaser, **DeSolv Degreaser**, to remove residual mastic remover from the substrate and to speed up the time between mastic removal and resurfacing. The degreaser is applied straight and scrubbed into the surface as water is added, with agitation, to 'float' the solvent out of the substrate.
- 9. Allow the surface to dry a minimum of 48-72 hours before applying new mastic and/or new flooring.

WARRANTY NOTICE: Seller makes no warranty, expressed or implied, nor accepts any responsibility for any direct or consequential damages beyond the purchase price, because seller cannot control users handling and use, or effect of use.