

## **Specifications:**

## Clean Air Low Odor Mastic Remover 5 gallon Pail and 55 Gallon Drum

Appearance: Clear Liquid

Odor: Extremely Low

Boiling Point: 410 - 550 F

Freezing Point: - 94 F

Vapor Density: NA

pH: NP

Flash Point: 174 F (TCC)

**DOT Shipping Class: 55** 

Shipping Weight: 5 gal. pail 35 lbs.

55 gal. drum 386 lbs.

Specific Gravity: 0.800 - 0.820

Solubility in Water: Nil

Coverage Rate: 100 to 125 sq ft / gal

Reactivity: Stable

HMIS Rating: 1-2-0

Shelf Life: None

DOT Shipping Name: Not DOT Regulated On containers less than 120 gallons

## Twin-Chemicals Atlanta, Georgia

(800) 442-4958 (770) 924-6147 fax

www.twinchemicals.com



Clean Air Low Odor Mastic Remover is an economical, fast acting, CARB Compliant, low odor mastic remover. This product is a hydro-treated petroleum base with a superior surfactant system that allows for easy rinsing and final cleaning. This product is a contractor favorite because it gets the job done and is extremely cost effective.

## Directions:

- 1. Read and understand the safety data sheet (SDS) when using this product.
- 2. Prepare a safe work area by; protecting walls, drains, cracks, carpeting, woodwork and any other surface that may come in contact with the mastic remover. Set up decontamination chambers and a negative air system.
- 3. Remove floor tile according to local and federal regulations.
- 4. Apply **Clean Air Low Odor** Mastic Remover to the defined areas, either manually or with a pump spray until areas are completely saturated. Agitate the product with a stiff bristled broom or brush.
- 5. Allow the mastic remover to penetrate and soften the adhesive for at least 20-30 minutes.
- 6. After the mastic has dissolved, use a squeegee to collect liquefied mastic in a pile and use **Mastasorb Absorbent** bales to soak up liquid. Dispose waste according to local and federal regulations.
- 7. Once the adhesives have been satisfactorily removed, use a wetting agent, **Pronto Extra Wetter**, to wet out and remaining particles to make certain they don't become airborne.
- 8. The final step is to use a heavy-duty degreaser, **Twin-Chem Degreaser**, to remove residual mastic remover from the substrate and to speed up the time between mastic removal and resurfacing. The degreaser is applied straight and scrubbed into the surface as water is added, with agitation, to 'float' the solvent out of the substrate.
- 9. Allow the surface to dry a minimum of 24-26 hours before applying new mastic

and/or new flooring.

